



- **NOCOLYSE FOOD**® is a BIO-disinfectant for surfaces.
- **NOCOLYSE FOOD**® is a product based on hydrogen peroxide (7.9%), ready for-use, conceived to be used exclusively with the diffusion appliances of the **NOCOTECH**® range.
- The association **NOCOLYSE FOOD**® / **NOCOSPRAY**® (or **NOCOMAX**®) is effective on all types of microorganisms : it enables surface disinfection treatments with a bactericidal, fungicidal, virucidal, yeasticidal, mycobactericidal, bacteriophagical et sporicidal efficiency.
- **NOCOLYSE FOOD**® is available in neutral fragrance.

REFERENCES AND PACKAGING

	Reference	Packaging
Neutral	4020.001	1 Litre
	4020.001-6	Box of 6 x 1 Litre
	4020.005	5 Litre Canister
	4020.020	20 Litre Canister

COMPOSITION

Stabilized hydrogen peroxide in solution 7.9% (79ml/l) • EC=231-765-0 / CAS=7722-84-1.

STORAGE

- Store the product in the original packaging, vertically and in a cool and well ventilated place.
- Shelf-life : In the closed original packaging : 2 years from manufacturing date.
Once opened : 2 months from opening date.

OXYPHARM

829 rue Marcel Paul
94500 Champigny-sur-Marne
commercial@oxypharm.net
T: +33 1 45 18 78 70

www.oxypharm.net



PRECAUTION FOR USE

- Refer to the material safety data sheet, available on request by email: commercial@oxypharm.net.

INSTRUCTIONS FOR USE

Protocol for curative use

- Follow the instructions for use of the diffusion appliance of the range NOCOTECH[®] (cf. user's manual and quickstart document).
- Attach the 1L bottle to the diffusion appliance NOCOSPRAY[®] or the 20L tank on the diffusion appliance NOCOMAX[®].
- On the device, set the volume (V) of the room to be treated according to the required treatment (cf. below efficiency table).
As an example : « 3 x V » means « 3 times the volume of the room to be treated ».
A 20m² room with a height of approximately 2,50m will have a volume of 20 x 2,50m = 50m³.
The device will have to be set on 3 x 50 = 150m³.
- After the end of diffusion, respect a dwell time as indicated in the below efficiency table (CT).

	Treatment duration : →	
	TREATMENT	
Bactericidal activity	5 x V	TC = 2 hours
Yeasticidal activity	3 x V	TC = 2 hours
Sporicidal activity	5 x V	TC = 2 hours
Mycobactericidal activity	7 x V	TC = 2 hours
Virucidal activity	5 x V	TC = 2 hours
Fungicidal activity	3 x V	TC = 2 hours
Bacteriophagocidal activity	3 x V	TC = 2 hours

- Bactericidal activity - Log reduction ≥ 5
- Yeasticidal activity - Log reduction ≥ 4
- Sporicidal activity - Log reduction ≥ 3
- Mycobactericidal activity - Log reduction ≥ 4
- Virucidal activity - Log reduction ≥ 4
- Fungicidal activity - Log reduction ≥ 4
- Bacteriophagocidal activity - Log reduction ≥ 4

Efficiency table - Norm NFT 72 281 (November 2014)

IMPORTANT :

- During diffusion time and dwell time, leave the room closed and do not enter. The treatment must be conducted with no human presence inside the room.
- To achieve the highest quality disinfection a stringent cleaning process should be carried out prior to treatment.
- Protocols indicated in the above efficiency table are conform to results obtained in laboratory tests conducted according to NF T 72 281 norm (November 2014).** Every user can however define and validate a protocol according to his/her own efficiency requirements.
- Log reductions shown in the above table are a minimum achieved as set by the norm protocol. Higher reductions are achievable – up to Log 6 reductions.

OXYPHARM

829 rue Marcel Paul
94500 Champigny-sur-Marne
commercial@oxypharm.net
T: +33 1 45 18 78 70

www.oxypharm.net

